

Say "Welcome" to wheelchair users

Access

Platform stairlifts for straight stairs

Ideally suited to: Retail Outlets; Offices; Schools; Colleges; Leisure Centres; Pubs & Clubs; Sports Stadia; Libraries; Museums; Theatres; Cinemas; Restaurants; Health Centres; Courts; Places of Worship; Exhibition Centres; Local Council and Government Buildings.



Easy to use



Call platform. Barrier arm rises automatically while front barrier and ramp remain in safety position.



Wheelchair user drives on and barrier arm automatically lowers and ramp rises.



The lift travels to the bottom of the stairs, then the front barrier and ramp operate automatically.

Safe and simple to operate...

Safety features

- Constant pressure controls for user or attendant.
- Overspeed governor.
- Barrier arms surround and protect the user, automatically locking down before the platform moves.
- Platform stops automatically when sensitive surfaces detect obstructions.
- Easy roll-on, roll-off ramps rise automatically to restrain the wheel-chair when the platform is in motion.
- A handrail is provided for passenger use.
- Non-slip platform floor.
- Complies with BS5776 Powered Stairlifts and designed to ISO9386-2.
- Complies with the Machinery Directive.



The lift can then fold away flat against the wall until needed.

Access

Will help you to comply with Part 'M Building Regulations "Access for Disabled People" and the "Disability Discrimination Act 1995"

Installation..

A platform stairlift is installed in about a day.

The rail for the wheelchair platform runs up one side of the stairway attached to either the side wall or to floor mounted supports.

No separate motor housing is required.
The lift runs off the normal power supply.

Builders work is not normally needed where the staircase is existing.

Technical Specification:

Maximum Load: 230kg (36 stone, wheelchair & occupant)

Speed of travel: 0.1m/s nominal

Drive system: Motorised carriage climbs up and down a rigid aluminium rail with positive rack and pinion drive and automatic brake.

Overspeed governor: Fitted as standard.

Carriage control: Joystick control on carriage.
Constant pressure control buttons at top and bottom.

Platform working area: 810mm x 1050mm.

Travel: Up to 10m.

Minimum/maximum rail angle: 20°/45°

Stairlift rail: Can be wall mounted or structure supported.

Minimum clear stairway width: 1090mm - wall mounted rail.
1170mm - structure supported.

Power supply: 240v single phase.

Control Features

- Joystick control on carriage.
- Key switch and constant pressure push buttons on landings.
- Barrier arms and platform can be operated manually in an emergency.
- Platform ramps rise automatically as barrier arms lower.
- Lift operates only with platform and barrier down.
- Soft start and soft stop for maximum comfort and safety.



24 HOUR CALL OUT SERVICE

Crown Lifts Limited
Regency House
33-49 Farwig Lane
Bromley, Kent BR1 3RE

Telephone: 020-8464 5000

Facsimile: 020-8464 7646

Email: info@crownlifts.co.uk